



TECH TIPS

Dixie Part Numbers: S-6276 S-6281 S-6282

Applications: 2007 – 2009 Audi Q7 (all VIN numbers)
2007 – 2009 Audi Q7 (VIN numbers 000001 - 012000)

Condition: The operator may complain that during winter months in cold climates that the engine fails to start.

Cause: A possible cause for the above is excessive water build up in the exhaust system (predominantly on vehicles that are used for short trips). Condensation formed in the muffler has been found running back into the exhaust pipe and freezing. The plugged exhaust pipe will prevent the engine from starting.

Correction: The manufacturer has redesigned the rear muffler to correct this problem.

